## Yealink T41/T42 Quick Reference Guide

Placing a Call	Answering a Call	Holding and Muting a Call
<ol> <li>Pick up the handset OR</li> <li>Press the Obutton OR</li> <li>Press the Dutton</li> <li>Enter the number to call</li> <li>Press the Ok button OR</li> <li>Press the Dutton</li> </ol>	<ol> <li>Pick up the handset</li> <li>Press the Answer soft key OR</li> <li>Press the  button OR</li> <li>Press the  button</li> </ol>	<ol> <li>Press the Hold soft key</li> <li>Press the Resume soft key to resume the call</li> <li>Press the  button to mute the audio device</li> <li>Press the  button again to unmute the audio device</li> </ol>
Rejecting and Silencing a Call	Forwarding an Incoming Call	Transferring a Call
<ol> <li>Press the <b>Reject</b> soft key to send the call to directly to voicemail</li> <li>Press the <b>Silence</b> soft key to silence ringer and have the ability to answer the call within the designated number of rings</li> </ol>	<ol> <li>Press the Forward soft key</li> <li>Enter the number to forward call to</li> <li>Press the or button         OR     </li> <li>Press the from button         OR     </li> <li>Press the send soft key</li> </ol>	<ol> <li>Press the Tran soft key</li> <li>Enter number to transfer call to</li> <li>Press the Tran soft key</li> <li>Note: There is the option of speaking with the party to which the call will be transferred or to transfer after hearing the ring-back tone</li> </ol>
Initiating a Conference Call	Ending or Splitting a Conference Call	Managing a Conference Call
<ol> <li>Press the Conference soft on the active call screen</li> <li>Enter the number of the second party</li> <li>Press the or key         <ul> <li>OR</li> <li>Press the Conference soft key when the second party answers</li> </ul> </li> </ol>	<ol> <li>Press the EndCall soft key to terminate the call</li> <li>Press the Split soft key to split the call into two separate held calls</li> <li>Toggle between parties by pressing          <ul> <li>or → to select participant to speak with</li> <li>Press the Resume soft key</li> <li>Press the EndCall soft key</li> <li>Repeat steps 3-5 with the other call</li> </ul> </li> </ol>	<ol> <li>Press the Manage soft key on an active conference call</li> <li>Press the FarMute soft key to restrict a caller from speaking</li> <li>Press the Remove soft key to remove a caller from the conference call</li> </ol>

## Yealink T41/T42 Quick Reference Guide

	Searching for a Contact	Adding a Contact	Editing a Contact
1. 2. 3. 4. 5. 6.	Press the <b>Directory</b> soft key Select the desired directory type and press the <b>Enter</b> soft key Press the <b>Search</b> soft key Enter search criteria Select desired contact Press the <b>Send</b> soft key to call	<ol> <li>Press the Directory soft key</li> <li>Select the desired directory type and press the Enter soft key</li> <li>Press the Add soft key</li> <li>Enter contact information</li> <li>Press the Save soft key</li> </ol>	<ol> <li>Press the Directory soft key</li> <li>Select the desired directory type and press the Enter soft key</li> <li>Press the Search soft key</li> <li>Enter search criteria</li> <li>Press the Option soft key</li> <li>Edit information</li> <li>Press the Save soft key</li> </ol>
	Forwarding an Extension	Setting up Voicemail	Initiating Do Not Disturb (DND)
1. 2. 3. 4. 5. 6. 7.	Press the <b>Menu</b> soft key Highlight the <b>Features</b> and then press the <b>Enter</b> soft key Select <b>Call Forward</b> and then press the <b>Enter</b> soft key Select call forward type: a. <b>Always</b> b. <b>Busy</b> c. <b>No Answer</b> Press the <b>Enter</b> soft key and then the <b>Switch</b> soft key to enable Enter the destination number to forward all incoming calls to Press the <b>Save</b> soft key	<ol> <li>Press the B button or dial *123 to access the Message Center</li> <li>Enter default PIN (4-digit extension)</li> <li>Follow menu prompts</li> <li>Reset PIN         <ul> <li>a. 4 digits</li> <li>b. Non-sequential</li> <li>c. Different digits</li> </ul> </li> <li>Press the Connect soft key when alerted of a message         <ul> <li>OR</li> <li>Press the D button to access voicemail</li> </ul> </li> </ol>	<ol> <li>Press the DND soft key to enable</li> <li>Press the DND soft key again to disable</li> </ol>